

NISSAN PATHFINDER FROM 2005



USE CABLE C12 O HCS12, TAKE OFF BACK SIDE FROM DASH, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN OF BELOW PHOTO:

