

# NISSAN TERRANO2 FROM 2001



USE CABLE C4, OPEN BACK PART OF DASH, CAREFULLY, THEN LOCATE EPROM 93C66 OR S330 MEMORY, AND CLIP IT CHECKING PIN 1 AS SHOWN OF BELOW PHOTO:

**CLIP  
MEMORY  
93C66**

**ENIGMA**

