

NISSAN TERRANO2 TO 2001

ENIGMA



USE CABLE C12, REMOVE DASH FROM CAR, OPEN BACK COVER OF DASH, JUST PULL IT OUT. SOLDER POWER LEADS AND COLOUR LEADS LIKE WE CAN SEE ON NEXT PHOTOS ACCORDING TO COLOURS:

