

# OPEL MONTERREY



USE C7 CABLE, WE ONLY NEED REMOVE BACK PLASTIC COVER OF DASH, LOCATE POINTS IN THE MAIN BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US. **NEVER** TOUCH NAILS, IT IS VERY DANGEROUS. MEMORY INSIDE THESE KIND OF CARS ARE A 93C46

