

# ROVER 25



USE CABLE C4, REMOVE FRONT PLASTIC COVER, TAKE OFF SPEEDOMETER, ONLY FIXING WITH 4 SCREWS. THEN LOCATE EPROM MEMORY 93C46, CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

