

# SAAB 95 S220



USE CABLE C4, REMOVE REAR PLASTIC COVER. THEN LOCATE EPROM MEMORY 93C56 OR S220, AND CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

