

SUBARU FORESTER C56



USE CABLE C4, OPEN ALL DASH, PLEASE MAKE IT CAREFULLY, THEN LOCATE EPROM MEMORY 93C56(L56), USUALLY WE DON'T NEED TO DESOLDER IT, AND CLIP IT CHECKING **PIN 1** AS SHOWN OF PHOTO BELOW:

