SUZUKI JIMMY



USE C7 CABLE, OPEN DASH AND REMOVE SPEEDOMETER:



Now only solder cable leads according to points as shown on below photo:

