

SUZUKI SV650 INJECTION FROM 2002



USE CABLE C4, REMOVE BACK PLASTIC COVER FROM DASH, AND THEN LOCATE EPROM 93C46, AND CLIP IT CHECKING PIN 1 AS SHOWN OF BELOW PHOTO:

