

# TOYOTA AVENSIS



USE CABLE C4, OPEN ALL DASH, REMOVE NAILS CAREFULLY, THEN LOCATE EPROM 93C56 MEMORY, AND CLIP IT CHECKING PIN 1 AS SHOWN OF BELOW PHOTO:

