

TOYOTA AVENSIS C46



USE CABLE C5, OPEN BACK COVER, CAREFULLY, THEN LOCATE EPROM 93C46 MEMORY, AND CLIP IT CHECKING PIN 1 AS SHOWN OF BELOW PHOTO:

