

TOYOTA LANDCRUISER 2006



USE CABLE C4, REMOVE DASH FROM CAR, OPEN BACK COVER FROM DASH, AND THEN LOCATE EEPROM AND CLIP IT CHECKING **PIN 1** AS WE CAN SEE ON THIS PHOTO BELOW:

