TOYOTA RAV4 FROM 2005



USE **C7** CABLE, REMOVE BACK SIDE OF DASH, PUSH OUT SPEEDOMETER, THEN LOCATE POINTS ON THE MAIN BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

