

# VOLVO S40-V40



USE C7 CABLE, REMOVE DASH FROM CAR, WE MUST REMOVE OUT PLASTIC COVERS, THEN WE WILL HAVE BOARD WITH NAILS AND ENGINE, USUALLY WE MUST DESOLDER SCREEN, BUT WITH OUR METHOD THIS IS NOT NECESSARY. LOCATE POINTS ON THE BACK SIDE FROM MAIN BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

