

# VW CRAFTER EZS

USE CABLE **C45** + **A6 ADAPTER**. REMOVE MODULE FROM CAR CAREFULLY:



NOW REMOVE BACK PLASTICS COVERS FROM EZS, AND LOCATE POINTS ON THE BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

