

VW FOX



USE CABLE C12 OR C43, REMOVE BACK SIDE FROM DASH, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN OF BELOW PHOTO:

