Уамана **R1** То 2003



USE CABLE C7, OPEN BACK PART OF DASH, THEN LOCATE POINTS SHOWN OF BELOW PHOTO, AND THEN SOLDER CABLE LEADS CONCORDANCE WITH ITS NUMBER:

