

YAMAHA R6 FROM 2003 TO 2005



USE CABLE C7, OPEN BACK PLASTIC COVER FROM DASH, THEN LOCATES POINTS SHOWN OF BELOW PHOTO, AND THEN SOLDER CABLE LEADS CONCORDANCE WITH ITS NUMBER OR COLOUR:

