

YAMAHA R6 TO 2002



USE CABLE C7, OPEN BACK PART OF DASH, THEN LOCATE POINTS SHOWN OF BELOW PHOTO, AND THEN SOLDER CABLE LEADS CONCORDANCE WITH ITS NUMBER:

