

CITROEN C5 BSI 2004-06



USE CABLE C7, TAKE OFF BACK SIDE FROM BSI, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO PIN AS SHOWN OF BELOW PHOTO:

