

CITROEN NEMO 95080



USE CABLE C4, REMOVE DASH FROM CAR, OPEN ALL DASH, PLEASE MAKE IT CAREFULLY. WHEN WE HAVE MAIN BOARD ON OUR HANDS LOCATE EEPROM MEMORY, AND CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

