FERRARI F360 MODENA



USE CABLE C4, OPEN BACK PART OF DASH, CAREFULLY, THEN LOCATE EPROM 24CO2 MEMORY, AND CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

