

# FIAT BRAVO-BRAVA-MAREA 52



USE CABLE C11, REMOVE BACK COVER, LOOK FOR POINTS, AND SOLDER CABLE LEADS ACORDING TO COLOURS AS SHOWN OF PHOTO BELOW:

**DON'T FORGET TO MAKE A BRIDGE BETWEEN 3 POINTS:**

