

FIAT BRAVO-BRAVA-MAREA HC11



USE CABLE C11, REMOVE BACK COVER, LOOK FOR POINTS, AND SOLDER CABLE LEADS ACORDING TO COLOURS AS SHOWN OF PHOTO BELOW:

