

FORD C-MAX 2010



USE CABLE C4, REMOVE ALL PLASTIC COVERS FROM DASH, AND NAILS, CAREFULLY, THEN LOCATE EPROM MEMORY, AND CLIP IT CHECKING **PIN 1** AS SHOWN ON BELOW PHOTO:

