

FORD F250 2008



USE CABLE C12, REMOVE PLASTIC COVER FROM DASH, CAREFULLY, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN OF BELOW PHOTO:

