

FORD FOCUS AMERICAN VERSION



USE CABLE C12, REMOVE BACK PLASTIC COVER, YOU HAVE TO LOOK FOR POINTS ON THE MAIN BOARD AND SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN ON BELOW PHOTO:

