

FORD GALAXY FROM 2006



USE CABLE C12, OPEN BACK COVER FROM DASH, CAREFULLY, THEN SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN ON THE PHOTO BELOW:

