

FORD KA 2009



USE CABLE C4, OPEN ALL DASH, PLEASE MAKE IT CAREFULLY, THEN LOCATE EEPROM 93C56 AND CLIP IT CHECKING **PIN 1** AS SHOWN ON PHOTO BELOW:

