

FORD TAURUS



USE CABLE C12, REMOVE BACK COVER FROM DASH, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN ON BELOW PHOTO:

