

FORD TRANSIT FROM 2007



USE CABLE C4, CAREFULLY, THEN LOCATE EPROM MEMORY 93C76, AND CLIP IT CHECKING **PIN 1** AS SHOWN OF PHOTO BELOW:

