

# GMC YUKON 95080



USE CABLE C4, OPEN ALL DASH, PLEASE MAKE IT CAREFULLY, THEN LOCATE EPROM, AND CLIP IT CHECKING **PIN 1** AS SHOWN OF PHOTO BELOW:

