

HONDA VFR 800 TO 2001



USE C7 CABLE, REMOVE BACK PLASTIC COVER AND OPEN DASH, THEN LOCATE POINTS AND THEN SOLDER CABLE LEADS ACCORDING TO COLOUR:

