

# HONDA VRT FIRESTORM



USE C7 CABLE, OPEN OUTSIDE PLASTIC COVERS, LOCATE POINTS ON THE MAIN BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

