

# HONDA X-11



USE C7 CABLE, OPEN DASH, LOCATE POINTS ON THE BACK OF MAIN BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

