

HONDA CIVIC TYPE R TO 2003



USE C7 CABLE, REMOVE BACK COVER FROM DASH, LOCATE POINTS ON THE MAIN BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US, MEMORY INSIDE THOSE DASHES ARE 93C56:

