

HONDA S2000 C66

ENIGMA



USE CABLE C4, PULL OUT BACK PLASTIC COVER FROM DASH, MAKE ALL WORK CAREFULLY, THEN LOCATE EPROM 93C66, AND CLIP IT CHECKING PIN 1 AS SHOWN ON PHOTO BELOW:

