

# HYUNDAI SANTA FE FROM 2003



USE C7 CABLE, WE ONLY NEED TO REMOVE BACK COVER FROM DASH, LOCATE POINTS IN THE MAIN BOARD LIKE ON PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

