

HYUNDAI TERRACAN NEC



Use **CABLE C13 ALWAYS CONNECTED TO A1 ADAPTER**. OPEN COMPLETELY DASH, BE CAREFULLY WITH SCREEN, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO NUMBER AS SHOWN IN NEXT PHOTO:

