

IVECO DAILY & FURGON NEW



THESE ARE VERY SPECIAL DASH, IF YOU DON'T WANT TO HAVE ANY PROBLEM TAKE CARE OF NEXT INSTRUCTIONS:

- 1) TAKE OFF FRONT PLASTIC PART AND PUT DASH OUT.
- 2) PULL **RED** COVER CAREFULLY LOCATED IN FRONT OF DASH.
- 3) TAKE OFF A VERY SMALL SCREW UNDER THIS RED COVER.
- 4) PULL OUT TRANSPARENT COVER.
- 5) CAREFULLY TAKE OFF NAILS.
- 6) AND THE PLASTIC WHERE NUMBERS ARE PRINTED. IT IS A **STICKER**.
- 7) DRY OUT ALL **TORX** SCREWS THAT WE CAN FIND.
- 8) NOW WE HAVE BOARD FREE; LOCATE EPROM MEMORY **93CS56**, IT IS ON BACK SIDE OF SCREEN, AND CLIP IT USING CABLE **C4 - SMD CLIP**. CLIP IT CHECKING **PIN 1** AS SHOWN ON THE BELOW PHOTO:

