

JAGUAR S-TYPE FROM 2002



USE CABLE C12
OR HCS12,
TAKE OFF BACK
SIDE FROM
DASH, THEN
CONNECT OR
SOLDER CABLE
LEADS
ACCORDING TO
COLOURS AS
SHOWN ON
PHOTO:

