

# KAWASAKI W 650



USE CABLE C4, OPEN ALL DASH, PLEASE MAKE IT CAREFULLY, THEN LOCATE EEPROM MEMORY ON THE BOARD, AND CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

