

# KAWASAKI Z750



USE CABLE C4, OPEN BACK PLASTIC COVER FROM DASH, CAREFULLY REMOVE UPPER BOARD, THEN LOCATE EPROM MEMORY, AND CLIP IT CHECKING PIN 1 AS SHOWN INTO BELOW PHOTOS:

