KIA SPORTAGE S56



USE CABLE C4, OPEN ALL DASH, REMOVE NAIL CAREFULLY, THEN LOCATE EPROM 93S56 MEMORY, AND CLIP IT CHECKING PIN 1 AS SHOWN ON BELOW PHOTO:

