

LANCIA PHEDRA BSI TO 2005



USE CABLE C12 O HCS12, TAKE OFF BACK SIDE FROM BSI, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN OF BELOW PHOTO:

