

# LAND ROVER DEFENDER FROM 2007



USE CABLE C4, OPEN BACK COVER FROM DASH, LOCATE EEPROM M35080 MEMORY AND CLIP IT CHECKING **PIN 1** AS SHOWN OF PHOTO BELOW:

