

MERCEDES BENZ A-W169 DASH



USE CABLE C4, OPEN ALL DASH, PLEASE MAKE IT CAREFULLY, THEN LOCATE EEPROM 24C04, AND CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

