

MITSUBISHI OUTLANDER To 2006



USE CABLE C4, OPEN ALL DASH, COMPLETELY, THEN LOCATE EPROM UNDER SCREEN, BE CAREFULLY; SOMETIMES MUST BE CLEANED, AND CLIP IT CHECKING **PIN 1** AS SHOWN TO US PHOTO BELOW:

