

MITSUBISHI PAJERO FROM 2007



USE CABLE C4, REMOVE DASH FROM CAR, OPEN BACK COVER, AND THEN LOCATE EEPROM AND CLIP IT CHECKING PIN 1 AS WE CAN SEE ON THIS PHOTO BELOW:

