

MITSUBISHI SPACE WAGON



USE C7 CABLE, OPEN DASH AND REMOVE SPEDOMETER, AND THEN SOLDER CABLE LEADS ACCORDING TO ITS COLOUR AND POINTS SHOWN ON PHOTO BELOW:

